



Ref #	Part Number	Description	Qty
1	511-001	Collets Nut	1
2	511-002B	Collets 1/4"	1
3	501-004	Housing Cover	1
4	00-4177	O-Ring	1
5	501F-005	Clamp Nut	1
6	501-003	Spindle	1
7	00-2332	Ball Bearing	1
8	501-019	Front End Plate	1
9	00-3333	Spring Pin	2
10	00-3334	Spring Pin	1
11	501-006	Spacer	1
12	501-020	Rotor	1
13	221-021	Rotor Blade	4
14	221-022	Cylinder	1
15	221-023	Rear End Plate	1
16	00-2340	Ball Bearing	1
17	222F-045	Rear Gasket	1
18	222F-025	Motor Housing	1

Ref #	Part Number	Description	Qty.
19	00-4167	O-Ring	2
20	222F-026	Bushing	1
21	00-41187	O-Ring	1
22	00-41157	O-Ring	1
23	222F-027	Valve Stem	1
24	222F-029	Spring	1
25	00-4166	O-Ring	1
26	222F-030	Valve Plug	1
27	222F-037	Seal Lump	1
28	222F-043	Throttle Lever	1
29	222F-038	Muffler	5
30	222F-039	Exhaust Tube	1
31	222F-047	Muffler	1
32	222F-042	Exhaust Deflector	1
33	222F-050	Bushing	1
34	222F-034C	Air Inlet	1
35	511-007	Double Ended Wrench	2
36	00-4173	O-Ring	1