



Ref #	Part Number	Description	Qty
1	511-001	Collets Nut	1
2	511-002	Collets 6mm	1
3	511-003	Spindle	1
4	511-004	Housing Cover	1
5	00-4135	O-Ring	1
6	511-005	Clamp Nut	1
7	00-2314	Ball Bearing	1
8	00-3325	Spring Pin	1
9	511-019	Front End Plate	2
10	511-006	Spacer	1
11	216-021	Rotor Blade	1
12	511-020-B	Rotor	1
13	511-022	Cylinder	4
14	218F-023	Rear End Plate	1
15	00-2323	Ball Bearing	1
16	218F-045	Rear Gasket	1
17	218F-025	Motor Housing	1
18	00-41121	O-Ring	1
19	218F-026	Bushing	1

Ref #	Part Number	Description	Qty.
20	00-41133	O-Ring	1
21	00-41132	O-Ring	1
22	218F-027	Valve Stem	1
23	218F-029	Spring	1
24	551F-038	Regulator	1
25	00-4102	O-Ring	1
26	00-41134	O-Ring	1
27	551F-030	Valve Plug	1
28	218F-043	Throttle Lever	1
29	218F-038	Muffler	5
30	218F-039	Muffler Tube	1
31	218F-047	Muffler	1
32	218F-042	Exhaust Deflector	1
33	218F-050	Bushing	1
34	218F-034C	Air Inlet (1/4"NPT)	1
35	511-007	Double Ended Wrench	2
36	00-3328	Spring Pin	1
37	216-037	Seal Lump	1
38	00-4159	O-Ring	1