



Reference Number	Part Number	Description
1	90B-03	Snap Ring
2	90B-04	O-Ring
3	9ST316003	Valve Stem
4	90B-02	O-Ring (2)
5	9ST316005	Regulator
6	90B-06	Washer
7	9ST0B-08	Valve
8	90B-09-2	Spring
9	970426	Air Inlet
10	9SX-11.1	Stainless Mesh
11	9SX-11	Silencer
12	9ST246011	Sleeve
13	90B86811-1	Lever (Black)
14	90B86814	Pin
15	90B86813-3	Housing (AIRCAT)
16	970410	Retaining Ring
17	970048A	Bearing
18	9ST0B-19	Rear Plate
19	90B-20	Rotor Blade (5)
20	9ST0B-21	Rotor
21	9ST246021A	Cylinder
22	90B-23	Pin

Reference Number	Part Number	Description
23	90B86823A	O-Ring
24	981326	Pin
25	9ST0B-25	Front Plate
26	90B-26A	Bearing
27	90B-28.1	Washer
27A	90B-28	Washer
28	9E-29	Washer
29	9ST70407	Key
30	9STS560-29	Motor Shaft Balancer
31	90B-30	Snap Ring
33	90B-33	Snap Ring
34	9S560-34	Shaft
35	9ST246034	O-Ring
36	9RS0134	Lock Nut
37	9ST2460N36	Shroud
38	5437	PSA Pad (AIRCAT)
42	90B-39-22	Stop Spanner
45	90B-101-32A	Bearing
48	90B86848	Rubber Washer